
ITEM NO.	PART	QTY.	Heater Block Assembly PART NUMBERS		
1	Aluminum Heater Block	1		12V	24V
2	Cartridge Heater 40W, 12V or 24V	1	with Thermistor	MG11B-HT-12	MG11B-HT-24
3	Screw-on Thermistor with M3 stud	1	without Thermistor	MG11B-H-12	MG11B-H-24
4	Set Screw, M3 x 3	1			



NOTES:

5

Set Screw, M3 x 6

1. HEATER BLOCK SECURED ON HOTEND
BARREL WITH M3X6 SET SCREW (5). THIS
PREVENS BLOCK FROM TWIST DURING NOZZLE CHANGE.
2. JST CONNECTOR ON MODULAR THERMISTOR SHOULD BE
DISCONNECTED DURING THERMISTOR INSTALLATION OR REMOVAL
TO PREVENT TWISTING LEAD WIRES.

н				
	DIMENSIONS ARE IN MILLIMETERS [INCH]	TOLERANCES: ANGULAR: ± 1° .X ± 0.2 .XX ± 0.02 .XXX ± 0.005	THIRD ANGLE PROJECTION	
	DATE		MATERIAL	
	WEIGHT		FINISH	
-			1	_



RP One Labs

http://www.rp-one.com

+1 (917) 391-2322 info@rp-one.com

The work is licensed under GPLv3 licence Drawings - CC BY-SA 3.0 license

TITLE

MG Heater Block Assembly

SIZE	DWG. NO.		PART NO.		REV
Α	13051003		SEE TABLE		1.1
SCALE: 1:1		DO NOT SCALE DRAWING		SHEET 1 OF 1	

4 3